


Art nr: 78011 / 78013
Installationsanvisning / Assembly instruction

Installation:

1. Försäkra er om att spänning och frekvens på armaturen och nätet överensstämmer.
2. Fäst armaturen i taket med upphängningsbygeln (stor modell ska hängas i vajer, *fig.2*).
3. Anslut takkontakten, alternativt anslut till kopplingsplinten.

OBS! Om du vill använda takkopp, klipp av kabeln ungefär 10 cm från kontakten. Häng takkoppen i dess öglor och koppla kablarna till plinten, se *fig.3*. Vik sedan tillbaka takkoppen.


Byte av ljuskälla sker genom att lossa bländskyddets skruvar *fig.1*.

Installation:

1. Ensure that voltage and Hz on the fixture and mains voltage are the same.
2. Hang the fixture in the ceiling hook (large model should hang in a wire, *fig.2*).
3. Connect the plug or connect to the terminal block.

IMPORTANT! If you want to use the ceiling cup, cut the cable about 10 cm from the plug. Hang the cup on the ceiling hook and connect the cables to the terminal block, see *fig.3*. Fold up the cup toward the ceiling.

When changing light source, remove the diffuser by loosen the three screws *fig.1*.



Rengöringsinstruktioner och återvinningsanvisningar finns på www.zero.se
Cleaning and recycling instructions are available at www.zerolighting.com