





Installationsanvisning / Assembly instruction

Art nr: 16000 / 16001 / 16002 / 16003



Ljuskällan i denna armatur får endast bytas ut av tillverkaren eller av tillverkaren utsedd person.
The light source contained in this luminaire shall only be replaced by the manufacturer or a person designated by the manufacturer.

Denna produkt innehåller en ljuskälla med energieffektivitetsklass E / This product contains a light source of energy efficiency class E




16000/16001
16002/16003

Installation:

1. Försäkra er om att spänning och frekvens på armaturen och nätet överensstämmer.
2. Placera armaturen på ett stadigt underlag.
3. Glasskärmen monteras med låsskruv och styrbricka *gäller endast art.nr. 16000 och 16002, se fig. 1. En eller två brickor används beroende på glasets tjocklek.
4. Anslut armaturen.

Installation:

1. Ensure that voltage and Hz on the fixture and mains voltage are the same
2. Place the luminaire on a stable surface.
3. Mount the glass shade with supplied locking screw and washer *only applies to art. 16000 and 16002, see fig. 1. Depending on the glass thickness one or two washers are used.
4. Connect the plug.



Rengöringsinstruktioner och återvinningsanvisningar finns på www.zero.se
Cleaning and recycling instructions are available at www.zerolighting.com