






Installationsanvisning/Assembly instruction

Art nr: 191003 / 191003D



Ljuskällan och drivdonet i denna armatur får endast bytas ut av tillverkaren eller av tillverkaren utsedd person.
 The light source and control gear contained in this luminaire shall only be replaced by the manufacturer or a person designated by the manufacturer.

Denna produkt innehåller en ljuskälla med energieffektivitetsklass C / This product contains a light source of energy efficiency class C



191003
 191003D

Installation:

1. Försäkra er om att spänning och frekvens på armaturen och nätet överensstämmer.
2. Fäst armaturen i taket med upphängningsbygeln.
3. Anslut taktkontakten, alternativt anslut till kopplingsplinten.

OBS! Om du vill använda taktkopp klipp av kabeln ungefär 10 cm från kontakten. Häng taktkoppen i dess ögla och koppla kablarna till plinten, se fig.2. Vik sedan tillbaka taktkoppen.



Vid ljusreglering ska armaturen monteras av behörig installatör.

Installation:

1. Ensure that voltage and Hz on the fixture and mains voltage are the same.
2. Hang the fixture in the ceiling hook.
3. Connect the plug or connect to the terminal block.

IMPORTANT! If you want to use the ceiling cup, cut the cable about 10 cm from the plug. Hang the cup on the ceiling hook and connect the cables to the terminal block, see fig.2. Fold up the cup toward the ceiling.

Needs to be installed by electrician when dimmable version.



Rengöringsinstruktioner och återvinningsanvisningar finns på www.zero.se
 Cleaning and recycling instructions are available at www.zerolighting.com